रेखा (line)	लंबाई (Length) ground in meter	paper in cm	observed fore	back	d = fb - bb	f = d - 180°	e = E/2	corrected bearing fore	back	check
AB	35		60°30'	250°						
BC	28		145°	320°						
CA	40		275°	110°30'						

Scanned with CamScanner

Last (line)	Chain length ground in metre	Chain length ground in cm	Observed bearing fore	Observed bearing back	f = d − 180°	e = f/2	Corrected bearing fore	Corrected bearing back	check
AB	35		65°30′	240°					
BC	20		160°	320°					
CA	40		250°	100°30′					